

## TABELA PLANTOWANIA

Kilometraż		Hektometr	powierzchnia	powierzchnia śr.	Odl.	objętość
			plantowania	plantowania		plantowania
			m <sup>2</sup>	m <sup>2</sup>	m	m <sup>3</sup>
			1.	2.	4.	6.
0+	0,00	0,00	1,05			
0+	30,15	30,15	1,05	1,05	30,15	31,66
0+	55,15	25,00	1,60	1,33	25,00	33,13
0+	80,15	25,00	1,60	1,60	25,00	40,00
0+	105,15	25,00	1,60	1,65	25,00	41,25
0+	130,15	25,00	1,15	1,43	25,00	35,63
0+	155,15	25,00	0,80	0,98	25,00	24,38
0+	180,15	25,00	0,30	0,55	25,00	13,75
0+	205,15	25,00	0,30	0,30	25,00	7,50
0+	230,15	25,00	0,30	0,30	25,00	7,50
0+	255,15	25,00	0,40	0,35	25,00	8,75
0+	280,15	25,00	0,40	0,40	25,00	10,00
0+	305,15	25,00	0,65	0,53	25,00	13,13
0+	330,15	25,00	1,10	0,88	25,00	21,88
0+	355,15	25,00	1,35	1,23	25,00	30,63
SUMA:						319,16